

# MAINTENANCE KIT INSTRUCTIONS

For Use in HP 9000

---

**THE FOLLOWING PARTS ARE INCLUDED IN THIS MAINTENANCE KIT**

Part Description	Part Number	Quantity
Fusing Assembly	RG5-5750	1
Transfer Roller	RF5-3319	1
Tray 1 Feed Separation Roller	RF5-3404	2
Tray 1 Pick Up Roller	RF5-3403	1
Tray 2 & 3 Pick Up Roller	RF5-3340	2
Tray 2,3&4 Feed Separation Roller	RF5-3338	7
Instructions		1

**\*\*\*WARNING\*\*\***

**TURN PRINTER OFF, UNPLUG IT, THEN ALLOW PRINTER TO SIT  
FOR AT LEAST 30 MINUTES BEFORE PERFORMING  
MAINTENANCE PROCEDURES**



***Buy Smart. Waste Less. Save More!!***

Although you are not required, please do your part.  
Inside you will find an ARS tag provided for you to  
Recycle this product – Help keep America clean.

**“Do not use this tag for defective returns”  
Contact your supplier for a replacement fuser**

**\*\*\*\*WARNING\*\*\*\***

**TURN PRINTER OFF, UNPLUG IT, THEN ALLOW PRINTER TO SIT FOR AT LEAST 30 MINUTES BEFORE PERFORMING MAINTENANCE PROCEDURES**

### **Fusing Assembly Removal & Installation:**

1. Remove rear door and output bin.
2. Facing the back of the printer, locate the small blue levers on each side of the fuser assembly and rotate downward.
3. Lift up on the fuser handle slightly and pull the fuser out until it stops.
4. Grasp the blue handle on top of the fuser. Tilt the fuser and pull up slightly to remove.
5. Install replacement fuser in reverse fashion.
6. Make sure the blue envelope levers are in the down position.

**\*\*\*WARNING\*\*\***

**USE LATEX GLOVES WHEN REPLACING THE TRANSFER ROLLER  
\*\* DO NOT TOUCH THE BLACK FOAM ROLLER\*\***

### **Transfer Roller Replacement:**

1. Open the front door of the printer and rotate the large green lever downward.
2. Pinch the blue tab on the transfer roller assembly, below the toner cartridge, and pull it out of the printer.
3. Reverse for installation.
4. Make sure the new transfer assembly locks into place.

### **Pick Up Roller Removal & Replacement:**

1. Open tray 2 and pull it out until it stops. Remove the tray by lifting and pulling the tray free.
2. Repeat this step for tray 3.
3. Locate the rollers inside the paper tray slots.
4. Replace the rollers by pinching the tabs at the end of each roller.
5. Reinstall tray's 2 & 3.
6. Repeat this step for tray 4.

### **Reset the Maintenance Page Count: (plug in and leave power off)**

While pressing the (check mark) key, turn the printer on. When the three LED's are on, press the (triangle) key then press (check mark) key .



***Buy Smart. Waste Less. Save More!!***

Although you are not required, please do your part.  
Inside you will find an ARS tag provided for you to  
Recycle this product – Help keep America clean.